

AUTOMATIC RICE COOKER

SAFETY PRE-CAUTIONS

1. BE SURE THAT THE INSIDE OF THE RICE COOKER AND HEATING PLATE IS CLEAN, DRY, FREE OF RICE GRAINS AND FOREIGN MATTER BEFORE USING. THIS MAY AFFECT THE PERFORMANCE OF THE RICE COOKER AND DAMAGE HEATING ELEMENTS. (SEE FIG. 1)
2. BE SURE THAT THE OUTSIDE OF THE RICE PAN IS DRY BEFORE PLACING IT INTO THE RICE COOKER. ENSURE THAT THE RICE PAN IS SEATED PROPERLY INTO THE RICE COOKER TO ALLOW FULL CONTACT WITH THE HEATING ELEMENT. (SEE FIG. 2)
3. NEVER USE THE RICE COOKER TO BOIL ACID AND ALKALINE FOODSTUFFS. NEVER SUBMERSE RICE COOKER OR PLUG IN WATER. DO NOT LEAVE RICE COOKER IN A DAMP OR CORROSIVE ENVIRONMENT.
4. DO NOT PLUG RICE COOKER INTO OUTLET WITHOUT PLACING RICE PAN INSIDE FIRST. BE SURE TO UNPLUG RICE COOKER IF (1) YOU DO NOT WISH TO USE THE KEEP WARM CYCLE OR (2) WHEN YOU TAKE OUT THE RICE PAN.
5. DO NOT OPEN TOUCH OR OPEN LID WHILE RICE IS COOKING. SURFACES ARE HOT AND STEAM CAN CAUSE INJURY IF LID IS OPENED. USE EXTREME CARE AND POT HOLDERS WHEN REMOVING THE RICE PAN FROM THE RICE COOKER.
6. KEEP CHILDREN AWAY FROM RICE COOKER WHILE IN USE AND BE SURE TO PLACE THE WIRE PLUG IN A SAFE POSITION, AWAY FROM COUNTER EDGES TO AVOID ACCIDENTS.
7. THE RICE COOKER IS EQUIPPED WITH A SAFETY FUSE TO AUTOMATICALLY SHUT DOWN THE UNIT, THE UNIT WILL NOT WORK UNTIL THE FUSE IS REPLACED. (SEE FIG. 3)



AUTOMATIC RICE COOKER

INSTRUCTIONS FOR USE

General Instructions - How to Make Rice

Using the measuring cup, add rice to pan. Wash rice with cool water to remove any impurities in the rice until water becomes clear. Drain all of the water from pan. Use the measuring cup and add 2 cups of water for every 1 cup of rice. Optional: add 1 teaspoon of cooking oil per cup of rice if desired. Other spices may be added at this time to taste.

1. Thoroughly wipe and dry the outside of the rice pan before placing it into the Rice Cooker. Place the rice pan into the Rice Cooker and slightly turn it to the left and right to ensure that the rice pan is seated properly in the Rice Cooker (see fig. 1). Place glass cover lid on rice pan. Be sure to place the Rice Cooker on an even surface and away from counter edges.
2. Insert electrical appliance plug into the Rice Cooker, then plug into 220V (110V) outlet. Press the ON switch to start the Rice Cooker. (see fig. 2) Red light will come ON. Do not touch or open lid while rice is cooking. Keep children away from Rice Cooker at all times and place the wire plug in a safe position, away from counter edges, to avoid accidents.
3. When the rice is done, the Rice Cooker will automatically switch the Keep Warm cycle. The Red light will go OFF and the Yellow light will come ON. (see fig. 3) Do not open the lid. Keep the lid on for an additional 10-15 minutes to ensure that the rice is thoroughly cooked.
4. The Rice Cooker will keep the rice warm automatically to (60 degrees F, 80 degrees C). When the heat drops below this range, the Red light will come ON. (see fig. 4) and the Rice Cooker will automatically turn on and heat the rice. Unplug the Rice Cooker if you do not want to use this feature.
5. Always unplug the Rice Cooker when you take out the rice pan out and finish using it. Be sure to let the Rice Cooker cool down before touching, cleaning and storing away. Never submerge Rice Cooker or plug in water.



fig. 1



fig. 2




fig. 3




fig. 4