


Gas Fryer (Model GF-181) Spare Parts Exploded View

No.	Part Name	Qty.
1	Body, SUS 201	1
2	Oil Vale 6"	1
3	Tubing	1
4	Burner	1
5	Tracheal Group	1
6	Foot Cup	4
7	Bottom Plate	1
8	Battery Valve	1
9	Backplane 1	1
10	Backplane 2	1
11	Chimney Cover	1
12	Control Box	1
13	Slag Screen	1
14	Residue Insulation Plate	1
15	Lid Cover	1



— —

