



Hand Wash Station Instructions

Contents



Whats included:
- 2x Soap Dispensers, 1x Bowl, 1x Hand Wash Station

Attachment



To attach the soap dispensers, slide off the back and align the holes to the holes on the hand wash station.



Place the two small screws in the holes and slide the back of the soap dispenser down, then tighten. Once tightened you can then slide the soap dispenser on. Repeat process for other side.

Before First Use



Swarf developed from manufacture is commonly found inside the Hand Wash Station. Before first use, fill the product with water, then shake thoroughly, to remove any waste plastic found inside.



Make sure when you remove the tap, the water runs freely.

Trouble Shoot



This product is gravity fed which means a vacuum is formed when the lid is on tightly, stopping the water from flowing. Loosen the cap just enough, to allow air inside, which enables the water to flow at a steady trickle.

CONTACT US ON:

Tel: 01246 866 800

Website: www.tastytrotter.com

Email: info@tastytrotter.com

To see the desired rate of flow, scan here.

